

4 DIRECTV

- 4 >Know Your On-Screen Guide
- 5 DIRECTV Basics
- 8 DVR Essentials

Mobile Apps

3 > DIRECTV App

> Register Your Device to Your HD DVR

- 9 > Genie® HD DVR
- 10 > Connected HD DVR Features
- 12 > Sports Features
- 13 > Exclusive Programming

Troubleshooting

- 14 > Reset Your Receiver 15 > Technical Issues



This icon indicates a feature that you can enjoy when your HD DVR is connected to the Internet. Not connected? Learn how at directv.com/connect



Record your important account information here for easy reference.

With all your key information in one place, it's a snap to manage your account and get support when you need it.


General Information

Customer Name on Account	
Account Number	
SWiM Power Inserter Room Location	
Notes:	
Support	Social Media
Go to directv.com/help	facebook.com/DIRECTV
Call 800.531.5000 Para la información en español 888.388.6622	twitter.com/@DIRECTV
	· · · · · · · · · · · · · · · · · · ·

directv.com/recycle

ODIRECTV @DIRECTV

youtube.com/DIRECTV





_earn About Your New DIRECTV® Service

Find the answers you need anytime, 24 hours a day.



Customer Information Channel 🦃

Go to **Ch. 1001** on your TV to access a full library of short instructional videos. It's available On Demand anytime, 24 hours a day, and covers topics such as:

- > Remote Control Basics
- > Advanced Features
- > Using the On-Screen Guide
- > DIRECTY CINEMA®

Help Center

Visit the Help Center online at **directv.com/help** to get useful information and answers to FAQs. Plus, use the Live Chat feature and watch instructional videos.

>Live Chat

Chat with a specially trained agent to assist you in real time. Just look for the Live Chat pop-up screen.

Videos

Go to directv.com/intro to view tutorials on how to use the latest DIRECTV features and for quick troubleshooting solutions.



at no extra cost. you anywhere - no additional equipment needed, including your live and recorded shows, is with The same DIRECTV that you watch at home,

Req's Internet-connected Genie HR44+, DIRECTV App & elig, svc. Channels/content vary by pkg & location. Restrs apply. See back cover for DIRECTV App details.

GET STARTED

- > Download the **DIRECTV App** through your device's app store or at directv.com/download
- > Log in using your AT&T Access ID and password. create one at directv.com/myaccount) (Don't have a login account? No worries. Just
- Register your mobile device to your Internetto access your recorded shows. connected HD DVR (model HR44 or above)

Live TV Streaming

Content/channels/functionality varies. Data charges may apply Watch your live channels anywhere, Requires HR44 or above. on your mobile devices!

Movies, TV Shows and Networks

Availability of channels varies based on programming package subscription. Browse, watch or record shows, series or movies!

Recorded Shows

anywhere—without an Internet connection! your home DVR to your devices to watch Watch your recorded shows or download


Register your device to your HD DVR

Follow these easy steps: you're on the same Wi-Fi network as your receiver. When registering for the first time, make sure

- > Launch the DIRECTV App.
- > Tap WATCH YOUR DVR at the top of the
- > Tap MY DOWNLOADS (if you are on the same Wi-Fi network as your receiver).
- Tap GET STARTED and follow the prompts.



Game of Thrones® on HBO HB0° subscription required.



channel description

Favorite Channels

different family members. browse list or even create multiple lists for Organize all your favorites into an easy-to-



away or discover something new. Quickly get to your favorite channel right

QuickTune

channels so you can tune to them right away. Instantly access nine of your favorite, most-watched



Veep® on HBO

HBO*subscription required

- > Press the **INFO** button on the remote.
- > Use the **RIGHT ARROW** to highlight **FAVORITES**.
- > Select **SETUP CUSTOM 1** to choose your Favorite Channels list

> Scroll through the options, then press

SELECT to view a category.

> Press the **GUIDE** button twice to

search by category.

>Once your list is set, access it from here anytime.



Fixer Upper on HGTV

- > To access your QuickTune favorites at any time,



- > To add a favorite channel, press the UP ARROW add the channel. on your remote while watching. Press ENTER to
- press the **UP ARROW** on your remote.

DIRECTV Basics

One-Line On-Screen Guide

viewing your program on the full screen. See what's coming up without missing what's on. View the One-Line On-Screen Guide while



I'm Dying Up Here on ���������


> Press ENTER or the BLUE button SHOWTIME_® subscription required

Scroll through the guide one line at a time.

on your remote

DoublePlay

HR20 or later). Professional and collegiate sports subscriptions sold separately. Available with DVR Receivers (model R22 or later) or an HD DVR (model shows that are simultaneously recording. Quickly toggle between any two games or Don't miss a minute of your favorite shows.



While watching one program, press

> Press the **DOWN ARROW** again to the **DOWN ARROW** on your remote.

-- -- - - - - - - - different channal

Parental Controls

when you're not around. You can block spe Feel better knowing what your kids are wat channels and programs based on ratings and

times, plus set spending limits for Pay Per V



> Press **MENU** on your remote.

> Select SETTINGS & HELP, then PARENTAL CONTROLS.

Smart Search

Spend less time searching and more time watching with our intuitive search feature.

Available on all HD DVR and DVR Receivers (model RZ2 or later).



GameSearch™

When a game is blacked out, your receiver automatically searches for it on another channel. If you have a game set to be recorded, the receiver looks for it on an available channel and records it as scheduled.



Never Miss Your Favorite Shows

Catch every minute of your show or game, even if you don't have a DVR. AutoTune switches you to the channel you want to watch as soon as the action starts.

Available on all non-DVR Receivers



Fear the Walking Dead on almo

- > Press MENU on your remote.
- > Choose SEARCH & BROWSE, then SMART SEARCH.
- > Search by title, person, channel or keyword.
- >Scroll through the channel options until you find the one you're looking for, then press **SELECT.**
- > Tune to the game on the desired channel.
- > Follow the on-screen prompts and press **SELECT** to "Go to New Channel," if the option is available.
 - > Press **GUIDE** on your remote.
 - > Select the event or show you want to watch.
- > Highlight SET AUTOTUNE and press SELECT.

Record Shows

Press **RECORD** once to record an individual episode or twice to record an entire season.

Organize Playlist

Sort, delete and arrange your shows according to your preference.

Available on all HD DVR and DVR Receivers.

Enhance Your Live TV Experience

If you need to step away during your show, no worries. You won't miss a second of your entertainment.



The Daily Show with Trevor Noah on



Being Mary Jane on BET★



America's Got Talent on NBC

THE DUIT SHOW WITH HERVI

To access your recorded shows:

- > Press **LIST** on your remote.
- > Scroll to your desired recording and press **SELECT**.
- You can also pause, rewind and fast-forward anytime.

- > Press **LIST** on your remote.
- > Press the **DASH** or **YELLOW** button and choose from a variety of options.
 - >Press PAUSE during any live program or sporting event, then press PLAY when you're ready to resume.
- > You can then rewind or fast-forward to catch the exact moment you want to see



want to see, you can quickly go back. Hold the button down to jump to the end of the selected program. Press ADVANCE to scan your recorded show with a controlled 30-second FAST-FORWARD. If you spot something you

HD DVR in Every Room

of your choice at the same time. shows, from any room. Record up to five programs Pause and rewind live TV, plus record and delete

TV/Device for each additional TV. Limit three remote viewings per Genie HD DVR Requires one TV connected to a Genie HD DVR and a Genie Mini or DIRECTV Ready



Ray Donovan on TOWNIME

SHOWTIME_® subscription required.

> Press the **LIST** button to pull up your recordings, then refer to the **OPTIONS** prompt.

- >Scroll and select FILTER BY PLAYLIST.
- > Select ALL to view recordings from all TVs or LOCAL PLAYLIST to view a recording from the TV you are watching.

Picture in Picture (PIP)

change the channel. Watch two shows at once without having to

This feature is available only on the TV directly connected to Genie HD DVR.



Ballers® on **HB©**

HBO® subscription required.

- > Press the **INFO** button on your remote and select PIP.
- > Turn on **PIP** and select the **PIP** screen position.

Genie Recommends

Opt-in to Genie Recommends required. can't-miss shows that are on right now. about. Genie recommends the most popular, Find that new favorite show everyone's talking



Power on STARZ

STARZ® subscription required.

>Press **MENU** on your remote.

- > Select SEARCH & BROWSE.
- > Select TV SHOWS.

DIRECTV Connected HD DVR Features

All Seasons

available episode is arranged by season and plays Quickly locate and record entire seasons. Every automatically one after the other—binge-watching is easier than ever

restrictions, some episodes or seasons may be unavailable Available on select HD DVR Receivers (HR34 or later). Due to programmer



HBO® subscription required

> Press MENU, then SEARCH & BROWSE.

Use SMART SEARCH to find and

directv.com/connect

steps below. For all other receivers, visit If you have an HR44 or HR45, follow the

Connecting Genie® to the Internet

and hold the $\ensuremath{\mathsf{INFO}}$ remote button until the Info & Test Access to countless On Demand titles and more. Press screen appears on your TV. You'll find your receiver model in the "Receiver" line.



Family Guy on FOX

On Demand²

of titles that the whole family can e available On Demand anytime, includ Choose from thousands of shows a



There are multiple ways to access C

If you know the network channel nu > Enter a "1" in front of that number

72 Hour Rewind³ 🍣

DVR from the last 72 hours. Now you can watch select shows you forgot to (model HR20 or later). Available with DVR Receivers (model R22 or later) or an HD DVR

Restart³ 🔊

progress so you can watch from the very beginning. Tuned in late? Restart select shows already in Available with DVR Receivers (model R22 or later) or an HD DVR (model HR20 or later).

Pandora®4 🛸

music the app has discovered for you. that includes your favorites as well as new Pandora will create a personalized station Enter a favorite artist, track or genre and



Good Bones on HGTV



Search & Brow

>Look for the TRESTART ARROW in the channel guide.

- > Press **SELECT** on the remote to choose the show in progress.
- > Press the **REWIND** button and the show will start over.

> All On Demand content from the last 7 days

will appear in chronological order.

Navigate to MISSED IT? WATCH NOW!

and press SELECT.

> Press **SELECT** on the remote

name in the guide.

> Look for the + PLUS icon near the channel

- > Press **MENU** on your remote.
- > Select EXTRAS.
- > Choose PANDORA



Reminder: You have access to all of these additional features when your HD DVR is connected to the Internet.

DIRECTV Sports Features

Popular Sports

teams and even set your Genie® HD DVR to sport, date or time. Create a list of your favorite Browse current and upcoming games by record their every game.5



or missing a big play. instantly without changing your channel





SPORTSMIX® Channel®

Watch up to eight different sporting

highlights and analysis from popula Channel available in HD only. networks at the same time, all in HI



> Press **MENU** on your remote. > Select SEARCH & BROWSE.

· Calact CDODTC

> For Internet-connected HD DVRs, press the to access **SCOREGUIDE** from any channel. **RIGHT ARROW** button on your remote

time directly to that specific cha to hear audio for that channel. P

---- tha J77 bittos

Use the ARROW buttons to high

Tune to Ch. 205 SPORTSMIX.

Tennis and Golf Experiences

and more! Only available in HD. latest scores and leaderboards, access player bios, Open. Plus, watch up to 6 screens at once, check the and tennis events such as The Masters and French Watch exclusive expanded live coverage of major golf



> Visit directv.com/golf or directv.com/tennis for tournament dates and channel information.

>When you're tuned into any of the matches, press the **RED** button on your remote to get updates in real time.

AUDIENCE

to all DIRECTV customers. is uncut, commercial-free and available AT&T's original entertainment channel





Mr. Mercedes on AUDIENCE

Tune to Ch. 239 to enjoy:

> Original series: shows like Kingdom, You Me Her, Off Camera and more. Ice, Undeniable with Joe Buck,

> Groundbreaking documentaries: films that inspire, educate and entertain.

> Sports and entertainment news: live episodes of The Dan Patrick Show and The Rich Eisen Show every weekday.

DIRECTV CINEMA® Exclusives

and acclaimed indie films are added every month before they're in theaters. New hit movies Enjoy exclusive premieres on DIRECTV CINEMA®



The Last Face exclusively on DIRECTV CINEMA®

> Movies start on Ch. 125 and On Demand² Ch. 1000.

> Press **SELECT** to watch the movie you want to enjoy.

try this first!

> An easy solution for most problems: RESET YOUR RECEIVER.

trouble

Shootinc

Get quick solutions for resolving service queries on your own.

> Press the red **RESET** button next to the card slot on the receiver.



technical issues

No Internet Connection Dete on Your DIRECTV® Receiver Ethernet or coax cable is loose or d Additional Possible Causes Network settings on the receiver or router have changed.

in and its lights are on.

If you are experiencing problems with

connectivity, visit directv.com/conr

1. Check that the gateway is plugge

QUICK SOLUTIONS

Receiver has a poor connection to

wireless network.

2. Verify Internet service is active by checking your home computer.

Frozen/Pixelated Screen

Possible Cause

 Your receiver is having trouble communicating with your satellite dish.

QUICK SOLUTIONS

- 1. Check all connections on the back of your and make sure they're secure. receiver, starting with the SAT-IN connection,
- 2. Reset the receiver or Genie Mini by pressing the front panel. the device or inside the access card door on the red reset button located on the side of

No Signal/Snowy Screen

Possible Cause


 TV is on the wrong input, channel or audio/visual connection.

QUICK SOLUTIONS

- 1. Verify both TV and receiver are on.
- 2. On your **DIRECTV**® Remote, press **TV INPUT** and hold **ENTER** for 3 seconds. SOURCE button. On the RC71 remote, press OR on your TV remote, press the INPUT or
- > Cycle through inputs slowly until picture returns.
- 3. Check that all video cables between into matching ports. receiver and TV are securely plugged

the following components: Your DIRECTV® System may include





Wireless CCK

Wired CCK

(Video 1, 2, 3) A/V-RCA

(HDMI 1, 2, 3) HDMI



MIMS



Power Inserter

Component Cables

